

# **SPLASHBACK FITTING ADVICE**

**[1]** PLASTERED WALLS AND/OR TAPED AND FILLED JOINTS SHOULD BE PRIMED WITH PAINT OR PVA DILUTED 1:4 WITH WATER AND ALLOWED TO DRY PRIOR TO FIXING SPLASHBACKS

**[2]** WHEN FITTING LIGHTER COLOURED SPLASHBACKS ENSURE WALLS ARE UNIFORMLY PAINTED WHITE PRIOR TO FIXING

**[3]** DO NOT FIX SPLASHBACKS ON TOP OF TILES

**[4]** ONLY USE **LOW MODULUS NEUTRAL CURE CLEAR SILICONE**, AS SUPPLIED BY US. WE CANNOT GUARANTEE THAT ANY OTHER ADHESIVE WILL NOT REACT WITH THE PAINT

**[5]** APPLY SILICONE IN STAGGERED LINES – NOT BLOBS

**[6]** ENSURE THERE IS ADEQUATE SILICONE AROUND SOCKETS TO SUPPORT GLASS WHEN TIGHTENING COVER PLATE SCREWS

**[7]** ENSURE THERE IS NO GLASS / METAL CONTACT AT SOCKETS

**[8]** DON'T USE PAINTERS CAULK – IT MAY REACT WITH THE PAINT

WE CANNOT BE HELD LIABLE FOR ANY PAINT / ADHESIVE REACTION WHICH MIGHT OCCUR IF YOU DO NOT ADHERE TO THESE INSTRUCTIONS

**IF YOU HAVE ANY QUERIES PLEASE CALL OUR OFFICE PRIOR TO FIXING**

**FORSYTH GLAZING LTD**

**0141 554 0011**